

Claviorganum

sample-set for Cecilia Magna expander

Contains a very nice and specific combination of Cembalo stops and small positive organ.

- Source: Sonus Paradisi
- Instrument: Claviorganum - selection
- More information and demos:

<http://www.sonusparadisi.cz/en/organs/harpsichords-etc/claviorganum-sonus-paradisi.html>

Pedal	I. manual	II. manual
<ul style="list-style-type: none">• Bourdon 16'• Gedackt 8'• I:P• II:P	<ul style="list-style-type: none">• Cembalo 8'• Rohrfloet 8'• Spitzfloet 4'• Waldfloet 2'• Siffloet 1'• Tonus Fabri• Vox Humana 8'• II:I• Melody coupler• Bass coupler	<ul style="list-style-type: none">• Lute 8'• Gedackt 8'• Quintadena 8'• Kleingedackt 4'• Cymbal• Tremulant

Changing the sample-set

Individual sample-sets can be changed using a dedicated external FLASH disc. The procedure is quite simple:

1. Switch off the organ expander, disconnect the power adapter.
2. Disconnect the USB/MIDI cable and connect the dedicated FLASH disc to the USB connector.
3. Connect the power source again - the logo appears at the display. Within several seconds, the organ expander starts automatically the updating procedure.
4. After the process is completed, a main screen appears at the display. Now the new sample-set is ready.
5. **REMOVE** the flash disc, connect the USB/MIDI cable again and replace the magnetic labels above the stop tabs.

WARNING: user settings are replaced by default values during the process. So correct MIDI channels must be set again.

Labels for 25 mm magnetic strips or 20 mm magnetic C profile rails

Bourdon 16'	I:P	Cembalo 8'	Spitzfloet 4'	Siffloet 1'	Vox Hum. 8	Bass- couple	Lute 8'
Quintad. 8'	Cymbal						Ancient Clavierorgnum 1
Gedackt 8'	II:P	Rohrfloet 8'	Waldfloet 2'	Tonus Fabri	II:I	Melody- couple	Gedackt 8'
Klein Ged. 4'	Tremulant	Cymbel- stern					Ancient Clavierorgnum 2